


FIG.46

G - 11

74

FIG.46 ( G-11) RIGHT HANDLE SWITCH



REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	57110-49501	GRIP, throttle	1	
2-1	37200-45C01	SWITCH ASSY, handle, RH	1	
2-2	37200-45C21	SWITCH ASSY, handle, RH	1	model N/P/R E24
3	02112-05455	.SCREW	2	
4	57420-32C00	LEVER, adjust	1	
5	57430-40C00	KNOCKER	1	
6	57438-32C00	.SPRING	1	
7	57437-32C00	BOLT	1	
8	08319-31065	NUT	1	
9	57431-17C00	BOLT, lever	1	
10	08316-16064	NUT	1	
11	57460-17C00	SWITCH ASSY, stop	1	
12	57465-17C00	.SCREW	1	